

Fig. 1

FIG. 1 is a top view of a portable electronic device 10. The device 10 has a rectangular body with rounded corners. A display 34 is located at the top of the device. Below the display is a keypad 30. The keypad 30 includes a numeric keypad with circular keys and a set of function keys labeled 'A', 'B', and 'C'. A stylus 50 is shown resting on the keypad. The stylus 50 has a wavy, flexible tip 52 and a handle 56. A small rectangular component, possibly a battery or a connector, is located on the right side of the device. The device is labeled with the number 10 on the right side.

Fig.2




Fig.3




Fig.4




Fig.5




Fig. 6




Fig. 7




Fig.8




Fig. 9




Fig. 10




Fig.11




Fig.12




Fig.13




Fig. 14




Fig. 15




Fig.16




Fig. 17




Fig. 18




Fig. 19

Fig. 20




Fig.21




Fig. 22




Fig. 23